

INSTRUCTION SHEET Yamaha FJR 1300 REAR 2001-2005 141-0470-00

- Route the hose of the reservoir from the right side down. The Hose has to come out at the right side.
- Use the added hardware to mount the reservoir to the frame
- Mount the HPA adjuster knob also on the right side.
 See pictures. Use the added hardware to mount the adjuster knob to the frame.





ADDED HARDWARE :

| Bolt M6x25 | 2 pcs |
|----------------------------|-------|
| Bracket HPA | 1 pc |
| Bracket reservoir to frame | 2 pcs |
| Bracket reservoir | 2 pcs |