





Timing:

The ignition is fully installed and then timed using a timing light with the spark plugs removed and grounded in their caps with the base of the spark plugs laying on the cylinder fins so they can fire. Set the timing to the normal "S" mark by rotating the engine with the starter button.